QUICK FIX CHUCK HOLE FILLER

DIRECTIONS:

Clean area to be patched. Remove all loose particles, mud, dust, grass, etc. Use stiff broom. Then hose down thoroughly and allow to dry. Open can of **QUICK FIX** and empty into area to be patched. Level **QUICK FIX** by spreading with shovel, board or rake. Fresh **QUICK FIX** should be leveled about 1 inch higher than surrounding pavement to allow for compaction. A minimum final thickness of 2" is recommended.

CAUTIONARY INFORMATION: FOR PROFESSIONAL, COMMERCIAL, INSTITUTIONAL AND INDUSTRIAL USE ONLY

CAUTION:

KEEP OUT OF REACH OF CHILDREN

After area to be patched is filled, tamp with hand tamper, garden roller or any heavy flat object that will firmly compact the material. The more compaction, the better the patch. The newly paved area may normally be used immediately after being thoroughly compacted. However certain conditions, such as high temperatures, could delay the immediate use of area of traffic.

